

HINWEIS / INSTRUCTION

REINIGUNG DER BESPANNUNG CLEANING THE UMBRELLA COVER



HINWEIS

REINIGUNG DER BESPANNUNG

- 1 Oberfläche mit Reinigungsmittel einsprühen und ca. 1/2 Stunde einwirken lassen.

Empfohlenes Reinigungsmittel:

- Kärcher RM 555 (Baumärkte, OBI, Praktiker)

- 2 Bespannung mit Dampfstrahler absprühen.

Achtung: zum Schutz der Imprägnierung Folgendes beachten:

Temperatur: max. 30° C

Druck: max. 30 bar

Abstand der Düse zum Textil: 10 - 30 cm

- 3 Nach dem Waschen, Temperaturregler auf "Kalt" stellen und Bespannung so lange absprühen, bis sich kein Schaum mehr bildet.

- 4 Schirm in geöffnetem Zustand trocknen lassen, um Faltenbildung zu vermeiden.

INSTRUCTION

CLEANING THE UMBRELLA COVER

- 1 Spray fabric with cleaning agent and leave for approx. 30 minutes.

Recommended cleaning agent:

- Kärcher RM 555 (DIY stores, OBI, Praktiker)

- 2 Spray cover with high-pressure cleaner.

Caution: observe the following to retain impregnation:

Temperature: max. 30° C

Pressure: max. 30 bar

Distance between cleaner nozzle and fabric: 10 – 30 cm

- 3 After washing, set temperature to 'Cold' and spray fabric until foam is no longer formed.

- 4 Leave umbrella fully extended to dry. This will prevent creases forming.

REINIGUNGSSCHRITTE / CLEANING INSTRUCTIONS

